











S800H





FAAC

CASSETTA PORTANTE-BEARING CASE-CASSON PORTANT TRAGEGEHÄUSE-CAJA PORTANTE- BEHUIZING

 Quote in mm - Dimensions in mm - Cotes en mm - Maße in mm - Cotas en mm - Waarden in mm





⚠ PER GARANTIRE UNA CORRETTA INSTALLAZIONE OCCORRE CHE L'ASSE DI ROTAZIONE DELL'ANTA, SIA PERFETTAMENTE ALLINEATO CON L'OPERATORE (Fig. 7)



TO ENSURE CORRECT INSTALLATION, THE LEAF ROTATION AXIS MUST BE PERFECTLY ALIGNED WITH THE OPERATOR (Fig. 7)

POUR GARANTIR UNE INSTALLATION CORRECTE, L'AXE DE ROTATION DU VANTAIL DOIT ÊTRE PARFAITEMENT ALIGNÉ SUR L'OPÉRATEUR (Fig. 7)

ZUR GEWÄHRLEISTUNG EINER SACHGEMÄSSEN MONTAGE MUSS DIE DREHACHSE DES FLÜGELS PERFECT ZUM ANTRIEB GEFLUCHTET SEIN (Abb. 7)

PARA GARANTIZAR UNA CORRECTA INSTALACIÓN ES NECESARIO QUE EL EJE DE ROTACIÓN DE LA HOJA ESTÉ PERFECTAMENTE ALINEADO CON EL OPERADOR (Fig. 7)

OM EEN CORRECTE INSTALLATIE TE GARANDEREN MOET DE ROTATIE-AS VAN DE VLEUGEL PERFECT OP EEN LIJN ZIJN MET DE AANDRIJVING (Fig. 7)



AUTOMATED SYSTEM S800H

CE DECLARATION OF CONFORMITY FOR MACHINES

(DIRECTIVE 2006/42/EC)

Manufacturer: FAAC S.p.A.

Address: Via Benini, 1 - 40069 Zola Predosa BOLOGNA - ITALY

Declares that: Operator model S800H

is built to be integrated into a machine or to be assembled with other machinery to create a machine under the provisions of Directive 2006/42/EC

conforms to the essential safety requirements of the following EEC directives

2006/95/EC Low Voltage directive

2004/108/EC Electromagnetic Compatibility directive

and also declares that it is prohibited to put into service the machinery until the machine in which it will be integrated or of which it will become a component has been identified and declared as conforming to the conditions of Directive 89/392/EEC and subsequent modifications assimilated in Italian National legislation under Presidential decree No.459 of 24 July 1996

Bologna, 01/01/2011

The Managing Director
A.Marcellan



ENGLISH

WARNINGS FOR THE INSTALLER

GENERAL SAFETY OBLIGATIONS

- 1) **ATTENTION! To ensure the safety of people, it is important that you read all the following instructions. Incorrect installation or incorrect use of the product could cause serious harm to people.**
- 2) **Carefully read and follow the instructions before beginning to install the product.**
- 3) Do not leave packing materials (plastic, polystyrene, etc.) within reach of children as such materials are potential sources of danger.
- 4) Store these instructions for future reference.
- 5) This product was designed and built strictly for the use indicated in this documentation. Any other use, not expressly indicated here, could compromise the good condition/operation of the product and/or be a source of danger.
- 6) FAAC declines all liability caused by improper use or use other than that for which the automated system was intended.
- 7) Do not install the equipment in an explosive atmosphere: the presence of inflammable gas or fumes is a serious danger to safety.
- 8) The mechanical parts must conform to the provisions of Standards EN 12604 and EN 12605.
For non-EU countries, to obtain an adequate level of safety, the Standards mentioned above must be observed, in addition to national legal regulations.
- 9) FAAC is not responsible for failure to observe Good Technique in the construction of the closing elements to be motorised, or for any deformation that may occur during use.
- 10) The installation must conform to Standards EN 12453 and EN 12445.
For non-EU countries, to obtain an adequate level of safety, the Standards mentioned above must be observed, in addition to national legal regulations.
- 11) Before attempting any job on the system, cut out electrical power.
- 12) The mains power supply of the automated system must be fitted with an all-pole switch with contact opening distance of 3mm or greater. Use of a 6A thermal breaker with all-pole circuit break is recommended.
- 13) Make sure that a differential switch with threshold of 0.03 A is fitted upstream of the system.
- 14) Make sure that the earthing system is perfectly constructed, and connect metal parts of the means of the closure to it.
- 15) The automated system is supplied with an intrinsic anti-crushing safety device consisting of a torque control. Nevertheless, its tripping threshold must be checked as specified in the Standards indicated at point 10.
- 16) The safety devices (EN 12978 standard) protect any danger areas against **mechanical movement Risks**, such as crushing, dragging, and shearing.
- 17) Use of at least one indicator-light (e.g. FAACLIGHT) is recommended for every system, as well as a warning sign adequately secured to the frame structure, in addition to the devices mentioned at point "16".
- 18) FAAC declines all liability as concerns safety and efficient operation of the automated system, if system components not produced by FAAC are used.
- 19) For maintenance, strictly use original parts by FAAC.
- 20) Do not in any way modify the components of the automated system.
- 21) The installer shall supply all information concerning manual operation of the system in case of an emergency, and shall hand over to the user the warnings handbook supplied with the product.
- 22) Do not allow children, things or adults to stay near the product while it is operating.
- 23) Keep remote controls or other pulse generators away from children, to prevent the automated system from being activated involuntarily.
- 24) Transit is permitted only when the automated system is idle.
- 25) The user must not attempt any kind of repair or direct action whatever and contact qualified personnel only.
- 26) Maintenance: check at least every 6 months the efficiency of the system, particularly the efficiency of the safety devices (including, where foreseen, the operator thrust force) and of the release devices.
- 27) **The S800H automated system automates vehicle entrances - pedestrians must have a separate entrance.**
- 28) Power up the automated system only when expressly indicated.
- 29) **Anything not expressly specified in these instructions is not permitted.**

1 DESCRIPTION

These instructions apply to the following models:

S800H SB/SBW - S800H CBAC / 100° - 180°.

FAAC S800H is an automated system in a hydraulic enbloc (CLASS III), permitting vehicle access through swing leaf gates which, when installed invisibly in the ground, does not alter the appearance of the gate. The model with a hydraulic shut-down facility does not require installation of an electrical lock, as it guarantees mechanical shut-down of the leaf up to 2 m when the motor is not operating. The model without a hydraulic shut-down facility always requires one or more electrical locks to ensure the leaf is mechanically shut down. **The S800H automated systems were designed and built to automate swing leaf gates. Do not use for any other purpose.**





Fig.1

2 TECHNICAL SPECIFICATIONS

TECHNICAL SPECIFICATIONS	CBAC OPERATOR	SB/SBW OPERATOR
Power supply (V dc)	24	
Absorbed power (W)	60 (*)	
Protection class	IP 67	
Type of oil	FAAC HP OIL	
Operating ambient temperature	-20° C +55°C	
Rated Operating Time (R.O.T.)	Continuous duty at 55°C	
Hydraulic shut-down facility	Supplied	Not supplied
Max. torque (Nm) **	500 (E024S7) ; 600 (E124)	
Angular speed (°/sec) ***	5.5 (E024S) ; 8.2 (E124)	
Max opening angle ****	113° (S800H 100°) 187° (S800H 180°)	
Leaf max. length (m)	2	4
Leaf max. weight (Kg)	800	

* EACH INDIVIDUAL OPERATOR
 ** CONSIDERING 55 Bar OF STATIC PRESSURE IN THE CHAMBERS
 *** CONSIDERING A PUMP CAPACITY OF 0.6 lpm
 **** 3° OF TRAVEL ARE LOST WHILE THE OPERATOR IS BEING INSTALLED

3 ELECTRICAL PREPARATIONS



- ① S800H Operators with encoder
2x2.5 mm² / AVG 12 for motor (minimum)
(Max. length 20 m)
 2x0.5 mm² / AVG 20 for encoder bus
 (Max. length 100 m)
- ② Bus 2 Easy Photocells 2x0.5 mm² / AVG 20
 (Max. length 100 m)
- ③ Control unit
 (To be selected according to the installed power supply)
 2x2.5 mm² / AVG 12 for powering
- ④ Key operated push-button 2x0.5 mm² / AVG 20
- ⑤ Flashing lamp 24 V 2x1.5 mm² / AVG 16


Fig.2

4 INSTALLING THE OPERATOR

IMPORTANT: REMOVE THE ENCODER (Fig.1 ref. ⑨) BEFORE YOU BEGIN MECHANICAL INSTALLATION

4.1 OPERATOR WITHOUT MECHANICAL EMERGENCY RELEASE

- 1) Take the gate to its open position.
- 2) Consulting the instructions in chapter 7.1, hydraulically release the operator, using the key on the release screw (Fig. 3 ref.①)




- 3) On the operator, unscrew the plug (Fig.4 ref. A) of the screw of the closing travel limit device (Fig.4 ref. ①) and check if the screw is completely tight.


- 4) **Back off the closing travel limit screw (Fig.4 ref. B) by one turn (IMPORTANT FOR CORRECT COUPLING OF THE PINION-GROOVED BUSH DURING INSTALLATION).**

- 5) Turn the operator pinion with the supplied wrench (Fig. 5 ref. ①), **in the gate closing direction** as shown in Fig.5, up to the internal stop point of the piston, and remove the key.


- 6) **Without moving the pinion**, insert the supplied wrench on the operator as shown in Fig.6, and make sure that it indicates 0 (ZERO) on the operator's plastic panel (Fig.6 ref.①). If necessary rotate the pinion. **(IMPORTANT FOR CORRECT COUPLING OF THE PINION-GROOVED BUSH DURING INSTALLATION).**



TURN THE KEY TILL REACHING THE MECHANICAL STOP-POINT AND WITHDRAW IT FROM THE PINION



INSERT THE KEY WITHOUT MOVING THE PINION AND CHECK IF IT INDICATES ZERO



NOTE: if necessary, lightly screw the closing travel-limit screw

7) Remove the adjustment wrench, screw the plug of the travel limit screw and grease the pinion.

8) Using the handles, insert the operator in the bearing case as shown in Fig.7-8,

9) Close the gate.

10) Raise the operator with its handles (Fig.10 ref. A), inserting the pinion in the grooved bush of the bearing case. To facilitate the operation, slightly rotate the operator until coupling takes place.

referring to the instructions in chapter 5.

14) Close the gate and check if the closing travel-limit stop is correctly positioned; if necessary, adjust the travel-limit stop, referring to the instructions in chapter 5.

15) Hydraulically shut down the operator as per instructions in chapter 7.1.

16) As described in the instructions for the control board, make the electrical connections, taking care over encoder polarity.

17) Secure the cover of the bearing case with the supplied screws.




Fig.7




Fig.8




Fig.10

11) Place the supplied key under the operator, as shown in figure 10 ref. B, C

12) Insert and screw the fastening screws with groover and washer as shown in Fig. 10 ref. C, in order to secure the operator to the bearing case as shown in Fig. 11.

13) Open the gate and check if the opening travel-limit stop is correctly positioned; if necessary, adjust the travel-limit stop,




Fig.9




Fig.11

4.2 OPERATOR WITH MECHANICAL RELEASE

- 1) Take the gate to its open position.
- 2) Consulting the instructions in chapter 7.1, hydraulically release the operator, using the key (Fig. 1 ref. ⑩) on the release screw (Fig. 12 ref. ①)
- 3) On the operator, unscrew the cap (Fig. 13 ref. A) of the closing travel-limit screw (Fig. 13 ref. ①) and check if the screw is completely tight.
- 4) **Unscrew the closing travel-limit (Fig. 13 ref. ①) screw by one turn (IMPORTANT FOR CORRECT COUPLING OF THE PINION-MECHANICAL RELEASE DURING INSTALLATION).**
- 5) Turn the operator pinion with the supplied key, **in the gate closing direction** as shown in Fig. 14, up to the internal stop point of the piston, and remove the key.




Fig. 12





Fig. 13

- 6) **Without moving the pinion**, insert the supplied key on the operator as shown in Fig. 15, and make sure that it indicates 0 (ZERO) on the operator's plastic panel (Fig. 15 ref. ①). If necessary rotate the pinion.

(IMPORTANT FOR CORRECT COUPLING OF THE PINION-MECHANICAL RELEASE DURING INSTALLATION).

NOTE: if necessary, lightly screw the closing travel-limit screw.

TURN THE KEY TILL REACHING THE MECHANICAL STOP-POINT AND WITHDRAW IT FROM THE PINION




Fig. 14

INSERT THE KEY WITHOUT MOVING THE PINION AND CHECK IF IT INDICATES ZERO




Fig. 15

- 7) Remove the adjustment key and screw the cap of the travel-limit screw
- 8) Lightly grease the operator pinion.
- 9) Using the handles, insert the operator in the bearing case as shown in Fig.17 A,B
- 10) Take the gate to its **CLOSED** position.




Fig.16




Fig.17




Fig.18

- 11) Free the mechanical release, referring to paragraph 7.2.




Fig.19




Fig.20

- 12) Take the released gate into open position, making sure that the released part freed from the gate **remains in the gate closed position as shown in Fig.20 ref. ①.**

- 13) Raise the operator with its handles (Fig.21 ref. A), inserting the pinion in the grooved bush in the bearing case. To make the operation easier, slightly rotate the operator until coupling takes place.




Fig.21

- 14) Place the supplied key under the operator, as shown in figure 21, in order to support the motor.

- 15) Insert and screw the fastening screws with groover and washer as shown in Fig. 21 C, in order to secure the operator to the bearing case.

- 16) Close the gate and re-lock it to the mechanical release.




Fig.22

17) Open and close the gate, checking and, if necessary, adjusting the respective travel limit devices as described in chapter 5.

18) As described in the instructions for the control unit, make the electrical connections, taking care over encoder polarity.

19) Hydraulically shut down the operator as per instructions in chapter 7.1.

5 INTERNAL MECHANICAL TRAVEL-LIMIT STOPS (POSITIVE STOP)

The S800H operator is supplied standard with internal opening and closing mechanical stops. This is to facilitate the installation operations because there is no need to construct the mechanical stop elements.

The mechanical travel-limit stops (POSITIVE STOP) can be adjusted in the last 30° of the operator's MAXIMUM travel, at both opening and closing.

FAAC SUPPLIES THE TRAVEL LIMIT DEVICES TOTALLY OPEN (MAXIMUM PINION ROTATION ANGLE) ,

5.1 ADJUSTMENT OF THE TRAVEL-LIMIT STOPS

- 1) Hydraulically release the operator. (See chpt 7.1)
- 2) Close the leaf, manually taking it into its closed position.
- 3) Unscrew the cap (Fig.23 ref.A) of the closing travel-limit screw (Fig.23 ref.①)
- 4) UNSCREW the travel-limit stop screw (Fig.25 ref.B) at closing (Fig.25 ref.①), until the leaf begins to move.
- 5) Fasten the cap (Fig.23 ref.A) of the travel-limit stop screw.
- 6) Open the leaf, manually taking it into its opening position.
- 7) Unscrew the cap of the screw (Fig.23 ref.A) of the opening travel-limit stop (Fig.23 ref.②).
- 8) UNSCREW the travel-limit stop screw (Fig.23 ref. ②), until the leaf begins to move.
- 9) Fasten the cap of the travel-limit stop screw.
- 10) Open and close the gate to check if the travel-limit stop is correctly adjusted.
- 11) Shut-down the operator again, following the instructions in chapter 7.1.

6 FINAL OPERATIONS

⚠ To avoid excessive voltage drops, we recommend that the length of the motor cables with a section of 2.5 mm, should not exceed 20 m. The maximum total length of the BUS cables must not exceed 100 m.

- 1) Place the encoder in its seat on the motor.
- 2) Connect the motor (Fig.1 ref. ⑧) and the encoder (Fig.1 ref. ⑨) to the control unit, following the specific instructions.
- 3) Secure the cover of the bearing case with the supplied screws (Fig.24;25).
- 4) Where specified by current legal regulations, place at least two signs with the words "Danger: Automatic motion" on both sides of the automated system.

7 MANUAL OPERATION

⚠ BEFORE CARRYING OUT THE RELEASE AND SHUT-DOWN OPERATIONS, MAKE SURE THAT YOU HAVE CUT POWER TO THE OPERATOR AND THAT IT IS NOT MOVING




Fig.23




Fig.24




Fig.25

7.1 HYDRAULIC RELEASE OF THE OPERATOR

If the gate has to be moved manually due to a power cut or fault of the automated system, use the hydraulic release device with the release key (Fig.26 ref. ②):

- 1) Remove the cover from the bearing case.
- 2) Turn the release screw (Fig.26 ref.①) inserting the triangular recess of the supplied key (Fig.26 ref. ②):
 - To **RELEASE**, turn the screw anti-clockwise by one turn. (DO NOT COMPLETELY UNFASTEN THE SCREW TO AVOID OIL COMING OUT.
 - To **SHUT-DOWN** again, turn the screw clockwise up to the mechanical stop point.




Fig.26

7.2 MECHANICAL EMERGENCY RELEASE (OPTIONAL)

For the S800H operator, a manual mechanical emergency release is available as an optional item.

If the gate has to be moved manually due to a power cut or fault of the automated system, use the release key device.

The device is inserted on the gate support bracket (Fig.27 ref. ①) and enables you to release the system from both inside and outside the premises.




Fig.27




Fig.28

Procedure for manual leaf operation:

- 1) Open the protective hatch (Fig.28 ref. ②).
- 2) Insert the release key in the lock (Fig.28 ref. ③) and turn it clockwise up to its stop point.
- 3) Pull the release lever toward you (Fig.28 ref. ①).
- 4) Move the leaf by hand.

Procedure for restoring the system to normal operation:

- 1) Move the release lever back to its rest position (Fig.27).
- 2) Insert the release key in the lock (Fig.28 ref.③), turn it in the opposite direction up to the stop point and remove it.
- 3) Close the protective plug of the lock.
- 4) Move the leaf manually until it hooks on the shut-down bracket.

8 MAINTENANCE

Run a functional check of the system at least every 6 months, with special attention to the efficiency of the safety and release devices (including the thrust force of the operator), and to perfect operation of the gate hinges.

The safety devices installed on the system must be checked every 6 months.

8.1 BLEEDING OPERATIONS



THE S800H OPERATOR IS SUPPLIED WITH THE HYDRAULIC CIRCUIT ALREADY AIR FREE. DO NOT BLEED. BLEEDING IS ONLY NECESSARY IN THE EVENT OF MAINTENANCE OF THE HYDRAULIC SYSTEM OR TOPPING-UP OIL LEVEL.

The presence of air in the hydraulic circuit causes the automated system to operate incorrectly, i.e. a faulty movement of the leaf and too much noise while operating.

Procedure to avoid this problem:

- 1) Command the gate to open.
- 2) While the leaf is moving, loosen the opening bleed screw (Fig.29 ref.①)

- 3) Using the bleed screw, allow the air to come out from the hydraulic circuit until non-emulsified oil appears.
- 4) Tighten the bleed screw before the operator finishes the opening cycle.
- 5) Command the gate to close.
- 6) While the leaf is moving, loosen the closing bleed screw (Fig.29 ref. ②)
- 7) Using the bleed screw, allow the air to come out from the hydraulic circuit until non-emulsified oil appears.
- 8) Tighten the bleed screw before the operator finishes the closing cycle.
- 9) Repeat these operations several times.
- 10) Add oil till the oil level is just below the cap (Fig. 30, ref. ①)

ENGLISH




Fig.30




Fig.29

AUTOMATED SYSTEM S800H

USER'S GUIDE

GENERAL SAFETY REGULATIONS

If correctly installed and used, the S800H automated system ensures a high degree of safety.

Some simple rules on behaviour can prevent accidental trouble:

- Do not pass between the leaves when they are moving. Wait for the leaves to open fully before passing through them.
- Do not, on any account stay in between the leaves.
- Do not stand near the automated system, and do not allow children, persons or things to do so, especially when it is operating.
- Keep radio controls or other pulse generators away from children, to prevent the automated system from being activated involuntarily.
- Do not allow children to play with the automated system.
- Do not willingly obstruct leaf movement.
- Prevent any branches or shrubs from interfering with leaf movement.
- Keep the indicator-lights efficient and easy to see.
- Do not attempt to activate the leaves by hand unless you have released them.
- In the event of malfunctions, release the leaves to allow access and wait for qualified technical personnel to do the necessary work.
- When you have set manual operation mode, cut power to the system before restoring normal operation.
- Do not in any way modify the components of the automated system.
- Do not attempt any kind of repair or direct action whatever and contact qualified personnel only.
- At least every 6 month: arrange for qualified personnel to check the efficiency of the automated system and the safety devices.

DESCRIPTION

These instructions apply to the following models:

S800H SB - S800H CBAC

The FAAC S800H automated system for swing leaf gates is a hydraulic enbloc which, when installed invisibly in the ground, does not alter the appearance of the leaf.

The model with a hydraulic shut-down facility does not require installation of an electrical lock, as it guarantees mechanical shut-down of the leaf when the motor is not operating. The model without a hydraulic shut-down facility always requires one or more electrical locks to ensure the leaf is mechanically shut down.

The S800H automated systems were designed and built to automate swing leaf gates. Do not use for any other purpose. Leaves of up to 4 mt and 800 Kg can be automated depending on the selected model.

The functioning of the operators is controlled by an electronic control unit, housed in an enclosure with adequate degree of protection against atmosphere agents. The leaves are normally in closed position.

When the control unit receives an opening command via the radio control or any other pulse generator, it activates the hydraulic appliance which rotates the leaves until they reach the opening position to allow access.

If automatic mode was set, the leaves close automatically after selected pause time has elapsed.

If the semi-automatic mode was set, a second pulse must be sent to close the leaf again.

A stop pulse (if supplied) always stops movement.

For details on the behaviour of the automated system in different function logics, consult the installation Technician.

Automated systems include safety devices (photocells) that prevent the leaves from moving when there is an obstacle in the area they protect.

The S800H automated system is supplied standard with an electronic device which, when connected to a suitable control unit, detects the presence of a possible obstacle, and reverses the movement of the leaf.

The warning-light indicates the current leaf movement.

MANUAL OPERATION



WARNING: BEFORE CARRYING OUT THE RELEASE AND SHUT-DOWN OPERATIONS, MAKE SURE THAT YOU HAVE CUT POWER TO THE OPERATOR.

HYDRAULIC RELEASE OF THE OPERATOR

If the gate has to be moved manually due to a power cut or fault of the automated system, use the hydraulic release:

- 1) Unscrew the cover and remove it.
 - 2) Turn the release screw (Fig.1 ref.①) inserting the triangular recess of the supplied key (Fig.1 ref.②):
- To release, turn the release screw anti-clockwise up to the mechanical stop point.
 - To shut-down again, turn the release screw clockwise up to the mechanical stop point.




Fig.1




Fig. 1A

- To unlock, insert the key into the lock and turn clockwise until the mechanical stop.
- To re-lock, insert the key into the lock and turn it clockwise until it stops.

MECHANICAL EMERGENCY RELEASE (OPTIONAL)

For the S800H operator, a manual mechanical emergency release is available as an optional item.

If the gate has to be moved manually due to a power cut or fault of the automated system, use the release key device.

The device is inserted on the gate support bracket and enables you to release the system from both inside and outside the premises.

Procedure for manual leaf operation:

- 1) Open the protective hatch (Fig.3 ref.②).
- 2) Insert the release key in the lock (Fig.3 ref.③) and turn it clockwise sense up to its stop point.
- 3) Pull the release lever toward you (Fig.3 ref.①).
- 4) Move the leaf by hand.

Procedure for restoring the system to normal operation (Gate released):

- 1) Move the release lever back to its rest position (Fig.2)
- 2) Insert the release key in the lock, turn it in the opposite direction up to the stop point.
- 3) Move the leaf manually until the lock hooks on the shut-down bracket.
- 4) Close the protective plug of the lock.




Fig.2




Fig.3

MAINTENANCE

Every 6 months, arrange for a qualified technician to run a functional check of the system, with special attention to the efficiency of the safety and release devices, and to perfect operation of the gate hinges.

Also arrange a check of the quantity of oil inside the tank - **for any topping up, strictly use OLIO FAAC HP OIL only.**

MAINTENANCE REGISTER

System data

Installer	
Customer	
Type of system	
Serial No.	
Installation date	
Start-up	

System configuration

PART	MODEL	SERIAL NUMBER
Operator		
Safety device 1		
Safety device 2		
Pair of photocells 1		
Pair of photocells 2		
Control device 1		
Control device 2		
Radio control		
Flashing lamp		

Indication of residual risks and of foreseeable improper use

No.	Date	Job description	Signatures
1			Technician
			Customer
2			Technician
			Customer
3			Technician
			Customer
4			Technician
			Customer
5			Technician
			Customer
6			Technician
			Customer
7			Technician
			Customer
8			Technician
			Customer
9			Technician
			Customer
10			Technician
			Customer

Le descrizioni e le illustrazioni del presente manuale non sono impegnative. La FAAC si riserva il diritto, lasciando inalterate le caratteristiche essenziali dell'apparecchiatura, di apportare in qualunque momento e senza impegnarsi ad aggiornare la presente pubblicazione, le modifiche che essa ritiene convenienti per miglioramenti tecnici o per qualsiasi altra esigenza di carattere costruttivo o commerciale.

The descriptions and illustrations contained in the present manual are not binding. FAAC reserves the right, whilst leaving the main features of the equipments unaltered, to undertake any modifications it holds necessary for either technical or commercial reasons, at any time and without revising the present publication.

Les descriptions et les illustrations du présent manuel sont fournies à titre indicatif. FAAC se réserve le droit d'apporter à tout moment les modifications qu'elle jugera utiles sur ce produit tout en conservant les caractéristiques essentielles, sans devoir pour autant mettre à jour cette publication.

Die Beschreibungen und Abbildungen in vorliegendem Handbuch sind unverbindlich. FAAC behält sich das Recht vor, ohne die wesentlichen Eigenschaften dieses Gerätes zu verändern und ohne Verbindlichkeiten in Bezug auf die Neufassung der vorliegenden Anleitungen, technisch bzw. konstruktiv/kommerziell bedingte Verbesserungen vorzunehmen.

Las descripciones y las ilustraciones de este manual no comportan compromiso alguno. FAAC se reserva el derecho, dejando inmutadas las características esenciales de los aparatos, de aportar, en cualquier momento y sin comprometerse a poner al día la presente publicación, todas las modificaciones que considere oportunas para el perfeccionamiento técnico o para cualquier otro tipo de exigencia de carácter constructivo o comercial.

De beschrijvingen in deze handleiding zijn niet bindend. FAAC behoudt zich het recht voor op elk willekeurig moment de veranderingen aan te brengen die het bedrijf nuttig acht met het oog op technische verbeteringen of alle mogelijke andere productie- of commerciële eisen, waarbij de fundamentele eigenschappen van de apparaat gehandhaafd blijven, zonder zich daardoor te verplichten deze publicatie bij te werken.



FAAC

FAAC S.p.A.

Via Calari, 10

40069 Zola Predosa (BO) - ITALIA

Tel. 0039.051.61724 - Fax. 0039.051.758518

www.faac.it

www.faacgroup.com